



Pexip Infinity Hyper-V Installation Guide

Introduction

This document describes the minimum steps required to deploy and test a simple Pexip Infinity platform in a Hyper-V environment.

-  Full information on configuring and using Pexip Infinity is available:
 - on the [Pexip Infinity technical documentation website](#) (from where all documentation can also be downloaded in PDF format)
 - as online help, by clicking the **Help** link in the top right corner of the Pexip Infinity Administrator interface (available after the Management Node has been deployed).
-  You must ensure you have completed all necessary platform-based [Planning and prerequisites](#) prior to installation.

Configuring Hyper-V for Pexip Infinity

This section describes the Hyper-V configuration required before you [install the Management Node](#) or [install a Conferencing Node](#).

Supported Hyper-V versions

Version 14 of Pexip Infinity supports Microsoft Hyper-V in the form of Microsoft Hyper-V Server 2012 and later, or Windows Server 2012 and later.

Prerequisites

You must have a suitable Hyper-V environment already installed.

Synchronizing time

- i All host servers **must** be synchronized with accurate time before you install the Pexip Infinity Management Node or Conferencing Nodes on them.
- NTP **must** also be enabled on the Management Node VM before you deploy any Conferencing Nodes (this is done during installation of the Management Node).
- We strongly recommend that you configure at least three distinct NTP servers or NTP server pools on all your host servers and the Management Node itself. This will ensure that log entries from all nodes are properly synchronized.

In Hyper-V, all time synchronization is configured using the Active Domain Controller. You must ensure that all VMs and host servers are using the same time. Consult your Hyper-V documentation for information on how to do this in your environment.

Using a static MAC address for the Management Node

We recommend using a static MAC address for the virtual machine hosting your Management Node. This will ensure that the licenses on your Management Node do not become invalid if, for example, the node reboots and comes up on a different physical blade.

Creating an external virtual switch

You must create an external virtual switch on the host server to allow VMs on that host to access external network resources. To do this:

1. Log in to Hyper-V.
2. Right-click on the host server and select **Virtual Switch Manager...**
The Virtual Switch Manager window opens.
3. Select **External** and then **Create Virtual Switch**.
4. Enter a **Name** for the switch.
5. Either accept the default options, or select the options appropriate for your environment.
6. Select **Apply**.

Additional information

To look at the steps taken in setting up an example lab deployment of a Conferencing Node in Microsoft Hyper-V, see <http://www.graham-walsh.com/2016/02/setting-up-pexip-infinity-with-microsoft-hyper-v-server-2012/>.

Installing the Management Node

Before installing the Management Node we recommend that you review the [Hyper-V configuration prerequisites](#) and the [Installation checklist](#).

Installation of the Management Node is a two-step process:

1. **Deploying the VM template:** this creates a new unconfigured instance of a generic Management Node VM.
The process for deploying the template in a Microsoft Hyper-V hypervisor environment is described below.
2. **Running the installation wizard:** after deploying the Management Node template, the [installation wizard](#) allows you to enter the basic configuration details for your Management Node VM.

Deploying the Management Node template

To deploy a new instance of a Pexip Infinity Management Node using Hyper-V:

1. Download the **Pexip Infinity ZIP** file (Pexip_Infinity_v14_HyperV_pxMgr_<build>.zip) from www.pexip.com/software-download, and extract the files.
2. Log in to Hyper-V.
3. Right-click on the host server and select **Import Virtual Machine....**
This will start the Import Virtual Machine wizard.
4. On the **Locate Folder** page, **Browse** to the folder containing the extracted files and select **Next**.
You will be taken to the **Select Virtual Machine** page.
5. The wizard will automatically detect the folder and file containing the Management Node VM. Confirm that this is correct and select **Next**.
You will be taken to the **Choose Import Type Page**.
6. Select the type of import most appropriate for your environment (if you are unsure, select **Restore the virtual machine**).
Select **Next**.
7. Depending on the import type you have chosen, you may be asked for further information. Follow the prompts as required.
When the setup is complete, you will be taken to the **Completing Import Wizard** page.
8. Review the summary and select **Finish**.

When the Management Node VM has been created successfully, it will appear in the list of Virtual Machines.

Enabling automatic startup

By default, virtual machines deployed using Hyper-V are configured to restart automatically if they were running when the host server was shut down or powered off. We recommend that you leave this setting as is for the Management Node and all Conferencing Nodes.

Running the installation wizard

To run the installation wizard, which configures the Management Node, you must open a console window on the Management Node VM.

Opening a console window

1. Log in to Hyper-V.
2. Start the new Management Node VM (if it is not already running).
3. Right-click on the new Management Node VM and select **Connect....**

Running the installation wizard

- At the prompt, enter the username **admin**.
The display will read:
You are required to change your password immediately (root enforced)
Enter new UNIX password:
- Create a password for the Management Node operating system by typing the password, pressing enter, retyping the password, and pressing enter again.
- Ensure you record the password in a secure location. After you have finished running the installation wizard you will not need the password again unless you need to access the Management Node using SSH.
You are presented with another login prompt:
Running Pexip installation wizard...
[sudo] password for admin:
- Log in again with the password you just created.
The Pexip installation wizard will begin.
- Follow the prompts to set the following configuration for the Management Node.
If you press enter, the default value will be applied:

Setting	Default value	Multiple entries allowed?	Can be changed via Pexip Infinity Administrator interface?
IP address	192.168.0.100	No	No ‡
Network mask	255.255.255.0	No	No ‡
Gateway	192.168.0.1	No	No ‡
Hostname	<no default>	No	No ‡
Domain suffix	<no default>	No	No ‡
DNS servers	8.8.8.8	Yes, if separated by a space	Yes
NTP servers †	Two of the following: <ul style="list-style-type: none"> 0.pexip.pool.ntp.org 1.pexip.pool.ntp.org 2.pexip.pool.ntp.org 3.pexip.pool.ntp.org 	Yes, if separated by a space	Yes
Web administration username	admin	No	No ‡
Web administration password	<no default>	No	Yes
Enable incident reporting (yes/no)	<no default>		Yes
Send deployment and usage statistics to Pexip (yes/no)	<no default>		Yes

† The NTP server must be accessible by the Management Node at the time the startup wizard is run. Installation will fail if the Management Node is unable to synchronize its time with an NTP server.

‡ After they have been configured, do not attempt to change these settings by any other means. To change these settings on server-based deployments, you must re-run the installation wizard.

The installation will begin and the Management Node will restart using the values you have configured.

Initial platform configuration

After you have run the installation wizard, you must perform some preliminary configuration of the Pexip Infinity platform before you can then deploy a Conferencing Node.

This section lists the configuration required, and provides a summary of each step with a link to further information.

All configuration should be done using the Pexip Infinity Administrator interface.

Accessing the Pexip Infinity Administrator interface

The Pexip Infinity Administrator interface is hosted on the Management Node. To access this:

1. Open a web browser and type in the IP address or DNS name that you assigned to the Management Node using the installation wizard (you may need to wait a minute or so after installation is complete before you can access the Administrator interface).
2. Until you have uploaded appropriate TLS certificates to the Management Node, your browser may present you with a warning that the website's security certificate is not trusted. You should proceed, but upload appropriate TLS certificates to the Management Node (and Conferencing Nodes, when they have been created) as soon as possible.
The **Pexip Infinity Conferencing Platform** login page will appear.
3. Log in using the web administration username and password you set using the installation wizard.

You are now ready to begin configuring the Pexip Infinity service and deploying Conferencing Nodes.

As a first step, we strongly recommend that you configure at least 2 additional NTP servers or NTP server pools to ensure that log entries from all nodes are properly synchronized. For details, see [Enabling NTP on the Management Node](#).

Brief details of how to perform the initial configuration are given below. For complete information on how to configure your Pexip Infinity solution, see the Pexip Infinity technical documentation website at docs.pexip.com.

Configuring the Pexip Infinity platform

Enabling DNS

(System Configuration > DNS Servers)

At least one DNS server must be added to your system. DNS is required when using hostnames instead of IP addresses when setting up NTP servers, syslog servers and VM managers. It is also used for call routing that depends on FQDNs.

You will already have configured at least one DNS server when running the install wizard, but you can now change it or add more DNS servers.

See [Enabling DNS](#) for more information.

Enabling NTP

(System Configuration > NTP Servers)

Pexip Infinity uses NTP servers to obtain accurate system time. This is necessary to ensure correct operation, including configuration replication and log timestamps.

We strongly recommend that you configure at least 3 distinct NTP servers or NTP server pools to ensure that log entries from all nodes are properly synchronized.

You will already have configured at least one NTP server when running the install wizard, but you can now change it or add more NTP servers.

See [Enabling NTP on the Management Node](#) for more information.

Adding licenses

(Platform Configuration > Licenses)

You must install a system license with sufficient concurrent call capacity for your environment before you can place calls to Pexip Infinity services.

See [Pexip Infinity license installation and usage](#) for more information.

Adding a system location

(Platform Configuration > Locations)

These are labels that allow you to group together Conferencing Nodes that are in the same datacenter. You must have at least one location configured before you can deploy a Conferencing Node.

See [About system locations](#) for more information.

Uploading TLS certificates

(Platform Configuration > TLS Certificates)

You must install TLS certificates on the Management Node and each Conferencing Node. TLS certificates are used by these systems to verify their identity to clients connecting to them.

All nodes are deployed with self-signed certificates, but we strongly recommend they are replaced with ones signed by either an external CA or a trusted internal CA.

See [Managing TLS certificates](#) for more information.

Adding a Virtual Meeting Room

(Service Configuration > Virtual Meeting Rooms)

Conferences take place in Virtual Meeting Rooms and Virtual Auditoriums. Configuration includes any PINs required to access the conference.

See [Configuring Virtual Meeting Rooms](#) for more information.

Adding an alias for the Virtual Meeting Room

(done while adding the Virtual Meeting Room)

A Virtual Meeting Room or Virtual Auditorium can have more than one alias. Conference participants can access a Virtual Meeting Room or Virtual Auditorium by dialing any one of its aliases directly.

See [About aliases](#) for more information.

Manually deploying a Conferencing Node


Before you start, ensure that you are currently using the same machine that you will subsequently want to use to upload the generated file on to your host server.

To manually deploy a new Conferencing Node on to a Hyper-V host:

1. Go to **Platform Configuration > Conferencing Nodes** and select **Add Conferencing Node**.
2. From the **Deployment type** field, select **Manual (Hyper-V 2012)**.
3. Select **Next**.
4. You are now asked to provide information regarding the CPUs and memory of the Conferencing Node VM, by completing the following fields:

Option	Description
Number of virtual CPUs to assign	Enter the number of CPUs to assign to the Conferencing Node. You can make use of CPUs that support hyperthreading; see Achieving high density deployments with NUMA for more details.
System memory (in megabytes) to assign	Enter the amount of RAM (in megabytes) to assign to the Conferencing Node. The number entered must be a multiple of 4. We recommend 1024 MB (1 GB) RAM for each CPU.

5. Select **Next**.
6. You are now asked to provide the network configuration to be applied to the Conferencing Node, by completing the following fields:

Option	Description
Name	Enter the name that will be used to refer to this Conferencing Node in the Pexip Infinity Administrator interface.
Description	An optional field where you can provide more information about the Conferencing Node.
Hostname Domain	Enter the hostname and domain to be assigned to this Conferencing Node. Each Conferencing Node and Management Node must have a unique hostname. The Hostname and Domain together make up the Conferencing Node's DNS name or FQDN. We recommend you assign valid DNS names to all your Conferencing Nodes. For more information, see Assigning hostnames and FQDNs .
IPv4 address	Enter the IP address to be assigned to this Conferencing Node when it is created.
Network mask	Enter the IP network mask to be assigned to this Conferencing Node.
Gateway IPv4 address	Enter the IP address of the default gateway to be assigned to this Conferencing Node.
Secondary interface IPv4 address	The optional secondary interface IPv4 address for this Conferencing Node. If configured, this interface is used for signaling and media communications to clients, and the primary interface is used for communication with the Management Node and other Conferencing Nodes. For more information, see Deploying Conferencing Nodes with dual network interfaces .
Secondary interface network mask	The optional secondary interface network mask for this Conferencing Node.
System location	Select the physical location of this Conferencing Node. If the system location does not already exist, you can create a new one here by clicking  to the right of the field. This will open up a new window showing the Add System Location page. For further information see About system locations .
SIP TLS FQDN	A unique identity for this Conferencing Node, used in signaling SIP TLS Contact addresses. For more information, see SIP TLS FQDN .

Option	Description
TLS certificate	The TLS certificate to use on this node. This must be a certificate that contains the above SIP TLS FQDN. Each certificate is shown in the format <subject name> (<issuer>).
IPv6 address	The IPv6 address for this Conferencing Node. Each Conferencing Node must have a unique IPv6 address.
Gateway IPv6 address	The IPv6 address of the default gateway.
IPv4 static NAT address	The public IPv4 address used by this Conferencing Node when it is located behind a NAT device. Note that if you are using NAT, you must also configure your NAT device to route the Conferencing Node's IPv4 static NAT address to its IPv4 address. For more information, see Configuring Pexip Infinity nodes to work behind a static NAT device .
Static routes	From the list of Available Static routes, select the routes to assign to the node, and then use the right arrow to move the selected routes into the Chosen Static routes list. For more information, see Managing static routes .
Enable distributed database	This should usually be enabled (checked) for all Conferencing Nodes that are expected to be "always on", and disabled (unchecked) for nodes that are expected to only be powered on some of the time (e.g. nodes that are likely to only be operational during peak times).
SSH password	Enter the password to be used when logging in to this Conferencing Node's Linux operating system over SSH. The username will always be admin . Logging in to the operating system is required when changing passwords or for diagnostic purposes only, and should generally be done under the guidance of your Pexip authorized support representative. In particular, do not change any configuration using SSH — all changes should be made using the Pexip Infinity Administrator interface.

7. Select Finish.

You will be taken to the **Manually Deploy Conferencing Node** page.

8. Select Download Conferencing Node.

A zip file with the name **pexip-<hostname>.<domain>.zip** will be downloaded.

9. When you wish to deploy the Conferencing Nodes:

- Copy the zip file to the server running Hyper-V and unzip it.
You will see a subfolder called **Virtual Machines**, containing an XML file which contains the configuration for the Conferencing Node VM.
- Open the Hyper-V Manager and select **Import Virtual Machine...**
- Follow the on-screen prompts to deploy the Conferencing Node VM.
When prompted, select the **Virtual Machines** folder and the Hyper-V manager will automatically discover the XML file.
Select the type of import most appropriate for your environment (if you are unsure, select **Restore the virtual machine**).

After deploying a new Conferencing Node, it takes approximately 5 minutes before the node is available for conference hosting and for its status to be updated on the Management Node. (Until it is available, the Management Node will report the status of the Conferencing Node as having a last contacted and last updated date of "Never".)

To look at the steps taken in setting up an example lab deployment of a Conferencing Node in Microsoft Hyper-V, see <http://www.graham-walsh.com/2016/02/setting-up-pexip-infinity-with-microsoft-hyper-v-server-2012/>.

Enabling automatic startup

By default, virtual machines deployed using Hyper-V are configured to restart automatically if they were running when the host server was shut down or powered off. We recommend that you leave this setting as is for the Management Node and all Conferencing Nodes.

Disabling processor compatibility mode

We strongly recommend that you disable processor compatibility mode on all Hyper-V Conferencing Node virtual machines. If processor compatibility mode is enabled, the Conferencing Node may assume it is running on older hardware, and may stop working, with the message **CPU instruction set is not supported; system will be placed in maintenance mode**.

For more information, see <https://technet.microsoft.com/en-us/library/dn859550.aspx>.

Next steps after initial installation

Making a test call

When you have deployed a Conferencing Node and configured a Virtual Meeting Room and an alias, you can make a test call to check that your system is working.

An easy way to do this is by using the Infinity Connect Web App to dial the alias of one of the Virtual Meeting Rooms you've already created, as follows:

1. Open a browser (we recommend Chrome) and type in the IP address (or FQDN, if you've set it up already) of one of the Conferencing Nodes.
2. In the **Person or conference to call** field, enter the alias of the VMR you want to use for testing.
3. Select **Connect** and check your microphone, camera and speakers are working as expected.
4. Select **Start**.
You will be connected to the VMR.
5. From another machine, join the conference in the same way.

The two participants should be able to see and hear each other, and share content.

See [About the Infinity Connect Web App](#) for more information.

Further configuration

You are now ready to continue [configuring the Pexip Infinity platform](#) and [services](#) and deploying more [Conferencing Nodes](#).

Specifically, you should now do the following:

- [Assigning hostnames and FQDNs](#)
- [Enabling SNMP on Conferencing Nodes](#)

At some point you may also want to:

- [integrate the Pexip Infinity platform with your call control system](#)
- [configure the Pexip Distributed Gateway](#)
- [register devices directly to the Pexip Infinity platform](#)
- [customize the user experience](#)

Integrating with a call control system

To integrate Pexip Infinity with your call control system, you must configure a trunk or neighbor zone towards each of the Conferencing Nodes.

For further information about how to configure your specific call management system to work with Pexip Infinity, see the following documentation:

- [Pexip Infinity and Microsoft Lync / Skype for Business Deployment Guide](#)
- [Pexip Infinity and Cisco VCS Deployment Guide](#)
- [Pexip Infinity and Cisco Unified Communications Manager Deployment Guide](#)
- [Pexip Infinity and Polycom DMA Deployment Guide](#)

Configuring the Pexip Distributed Gateway

The Pexip Distributed Gateway service enables endpoints to make calls to other devices or systems that use different protocols and media formats.

For more information, see [About the Pexip Distributed Gateway service](#).

Registering devices directly to the Pexip Infinity platform

SIP and H.323 endpoints, and some Infinity Connect clients can register directly to Pexip Infinity Conferencing Nodes. This allows Pexip Infinity to route outbound calls to those registered devices without having to go via a SIP proxy or H.323 gatekeeper, or rely on DNS.

For more information, see [Registering devices to Pexip Infinity](#).

Customizing the user experience

You can easily apply your own corporate branding to the Pexip Infinity platform, and produce a personalized user experience for all of your Pexip Infinity services.

For more information, see [Customizing the user experience](#).

Pexip Infinity installation checklist

Use this checklist to identify the key tasks involved in preparing for and deploying the Pexip Infinity platform. Also, there is a configuration [datasheet](#) below to help you gather the key network and configuration information required.

Prior to installation

1. Download the appropriate Pexip Infinity Management Node installation file from www.pexip.com/software-download.
2. Ensure that you have appropriate host servers (see [Server design guidelines](#)).
3. Assign network IP addresses and host names for the Management Node and Conferencing Nodes.
4. Create DNS records for your Management Node administration.
5. Create DNS records to allow endpoints/clients to discover your Pexip Infinity Conferencing Nodes (see [DNS record examples](#)).
6. Generate or request certificates (Base64-encoded X.509 PEM format) for the Management Node and Conferencing Nodes (see guidelines at [Certificate creation and requirements](#)).

Hypervisor / host servers

1. Note the CPU model number and the number of cores per socket on the host server to be used with the Conferencing Nodes, as this determines the maximum number of vCPUs to assign for the Conferencing Nodes.
2. Prior to deploying the Management Node or a Conferencing Node, ensure that all host servers are synchronized to NTP servers.
3. Upload the OVA file (or ZIP for Hyper-V) of the Management Node and run the setup wizard from the hypervisor console.

Pexip Infinity Administrator interface

1. Configure basic Management Node settings after installation (licenses, VM managers, any additional DNS or NTP servers).
2. Add a system location.
3. Deploy Conferencing Nodes to the location (and use your hypervisor management tools for manual deployments).
4. Configure the SIP TLS FQDN on the Conferencing Nodes.
5. Verify your node's DNS records. (You can use the tool at <http://dns.pexip.com> to lookup and check SRV records for a domain.)
6. Replace the self-signed server certificates on the Management Node and Conferencing Nodes with your own certificates that have been signed by either an external CA or a trusted internal CA (see [Managing TLS certificates](#)).
7. Upload any required chain of intermediate CA certificates to the Management Node.
You can use a tool such as <https://www.sslshopper.com/ssl-checker.html> to verify certificates and the chain of trust (specify port 5061 i.e. use the format <domain>:5061 for the server hostname to ensure that SIP TLS connections are checked).
8. Configure your VMRs and aliases.
9. Configure the Pexip Distributed Gateway (via Call Routing Rules), if required.

Hypervisor maintenance

1. Enable automatic startup on every VM.
2. Backup your Management Node VM, and optionally, your Conferencing Node VMs.

Pexip Infinity configuration datasheet

Use this datasheet to help you gather the key network and configuration information required for your deployment.

Management Node (installation wizard)

Management Node IP address:

Network mask:

Gateway IP address:

Management Node hostname:

Management Node domain:

DNS server 1:

DNS server 2:

NTP server 1:

NTP server 2:

Management Node (configuration)

VM name:

System location 1 name:

License entitlement key:

VM manager IP/hostname:

(VMware automatic deployments only)

Conferencing Nodes

CPU cores per socket on host server:

(to determine the size of each node)

Conferencing Node 1 name / VM name:

Conferencing Node 1 IP address:

Conferencing Node 1 hostname and domain:

Conferencing Node 2 name / VM name:

Conferencing Node 2 IP address:

Conferencing Node 2 hostname and domain:

For complete information on how to configure your Pexip Infinity solution, see the Pexip Infinity technical documentation website at docs.pexip.com.